

CALDWELL

SOLUTIONS THAT SET NEW STANDARDS


Telephone 024 76437900

General Fitting Detail for Spinner Pivot

Fit the pivot hinge body into the outer frame profile on the centre line of daylight opening, and fix (into reinforcement on UPVC windows) with four suitable fixing screws (not supplied). Do not take the pivot apart in order to do this.

With the pivot still assembled, fit the Pivot Boss Plate to the centre line of sash profile, using similar screws.

The pivot hinge can be finely adjusted for centralisation by using the spindles at the top and bottom. Once centralised, these spindles can be used to adjust the friction of the hinge. Apply equal loading on each peg.



Note Caldwell Hardware offer a range of spinner pivots depending on system in use and specific application.

Please contact Caldwell Technical for further details.

All of the information shown on this data sheet was correct at the time of issue. All information however is subject to change and therefore it is advisable to check with Caldwell Hardware to ensure that you have the latest issue level.